

# INSTRUCTION MANUAL

## DM02 CLAMP MOUNT

READ FOLLOWING INSTRUCTIONS CAREFULLY BEFORE ATTEMPTING TO USE.  
PLEASE ALWAYS KEEP THIS MANUAL IN THE VICINITY OF USE FOR YOUR REFERENCE.  
BEFORE USING THE UNIT, CHECK IF THERE ARE ANY DAMAGES ON THE UNIT DUE TO  
TRANSPORT CONDITIONS. IF ANY DAMAGES ARE FOUND, CONTACT YOUR NEAREST  
DEALER.



**CAUTION** (INDICATES THAT INCORRECT OPERATION PRESENTS  
POSSIBILITY OF INJURY TO THE USER OR DAMAGE TO THE UNIT.)

1. Please do not place the finger between the clamping part.
2. Please tighten the screw firmly when you clamp the handpiece.
3. Please fix so as not to move when it installs in the tool-post of the lathe,  
and you fix to the stock vice.

### 1. USAGE AND FEATURE OF THIS PRODUCT

This Product is used for the clamping head, the gear joint, and the clamping joint of the product of our company are installed in the machine tool such as lathes, also, it can be used for the handpiece is placed between the stock vice etc, and it is fixed on the desk.

Therefore, the part of mount and the clamped handpiece become parallel.

### 2. SPECIFICATIONS

WEIGHT : 0.35 kg  
BODY : 100 X 25 X 12 mm  
CLAMP :  $\phi$  26 mm

**MINITOR CO., LTD. JAPAN**

21-1 Ryogoku 3-chome, Sumida-ku, Tokyo 130-0026 JAPAN

Phone +81 3 (6630) 5800 FAX +81 3 (6630) 5795