

5. TROUBLE SHOOTING

※ IF THE MAIN SWITCH DOES NOT TURN ON

- CHECK WHETHER THE A.C. CABLE IS CERTAINLY PLUGGED IN OR NOT.
- CHECK WHETHER THE FUSE IS BURNT OUT OR NOT.

※ IF THE HANDPIECE DOES NOT OPERATE.

- CHECK WHETHER THE CURLED CORD IS CERTAINLY CONNECTED TO D.C.MOTOR SOCKET OR NOT.
- CHECK WHETHER THE COLLET RELEASE RING OF THE HANDPIECE IS IN "SET" POSITION.
- CHECK WHETHER THE FOOT SWITCH IS CONNECTED OR NOT. WHEN THE FOOT SWITCH IS CONNECTED, THE REMOTE SWITCH AND ON/OFF SWITCH WILL NOT OPERATE.

ANY OTHER TROUBLES OR OBSCURE POINTS, PLEASE CONTACT OUR MINITOR DEALER.

[P101 · P111 · P121 SPECIFICATIONS]

- INPUT VOLTAGE P 1 0 1 AC100V ± 5% 50/60 Hz
 P 1 1 1 AC115V ± 5% 50/60 Hz
 P 1 2 1 AC230V ± 5% 50/60 Hz
- RATING INPUT 3 0 V A
- OUTPUT VOLTAGE AC MAX 80V(25 ± 5KHz)
- SAFETY SYSTEM WHEN THE OUTPUT CURRENT FLOWS MORE THAN 0.32 A, THE OUTPUT CURRENT WILL BE SHUT DOWN INSTANTLY.
- OPERATING TEMPERATURE AND HUMIDITY RANGE 0° ~ 40° C AND 20 ~ 80% (NO CONDENSATION)
- DIMENSIONS 144 (W) × 218 (D) × 116 (H)
- WEIGHT APPROX. 1.7 Kg

MINITOR CO., LTD. JAPAN

16-3 Ryogoku 1-chome, Sumida-ku, Tokyo 130-0026 JAPAN

Phone +81 3 (3633) 7181 FAX +81 3 (3633) 7186

Products are subject to change without notice.

INSTRUCTION MANUAL

POLYTOR POWER PACK P 1 0 1 · P 1 1 1 · P 1 2 1

READ FOLLOWING INSTRUCTIONS THOROUGHLY BEFORE ATTEMPTING TO USE.
 ALSO READ THE INSTRUCTION MANUAL OF THE HANDPIECE AS WELL.
 KEEP THIS MANUAL ALWAYS IN THE VICINITY OF USE FOR YOUR REFERENCE.
 BEFORE USING THE UNIT, CHECK IF THERE ARE ANY DAMAGES ON THE UNIT DUE TO TRANSPORT CONDITIONS. IF ANY DAMAGES ARE FOUND, CONTACT OUR MINIMO DEALER.

SAFETY PRECAUTIONS



WARNING (INDICATES THAT INCORRECT OPERATION PRESENTS SIGNIFICANT DANGER OF ACCIDENT RESULTING IN DEATH OR SERIOUS INJURY TO THE USER.)

- WEAR AN APPROPRIATE EYE PROTECTION AND A DUST PROTECTING MASK WHEN USING THE HANDPIECE.
- DO NOT PLACE THE POWER PACK ON A STAND WHICH IS TILTED OR TOTTERY.
- TURN OFF THE MAIN SWITCH IMMEDIATELY AND UNPLUG THE A.C. CABLE WHEN ONE OR MORE OF THE FOLLOWINGS ARE RECOGNIZED; SMOKING, NASTY SMELL AND STRANGE NOISE FROM THE POWER PACK.
- NEVER TOUCH THE PLUG AND THE UNIT WITH WET HANDS.
- DO NOT DISASSEMBLE AND REMODEL THE UNIT. ANY ACCIDENT OR MALFUNCTION CAUSED BY DISASSEMBLING AND/OR REMODELING WILL NOT BE COVERED BY OUR RESPONSIBILITY.
- NEVER USE THE POWER PACK WITH THE INPUT VOLTAGE OTHER THAN THE ONE INDICATED ON BACK OF THE UNIT.
- DO NOT COVER AND/OR SEAL THE VENTILATOR.
- REPLACE THE POWER CABLE WITH NEW ONE WHEN DAMAGED. IT MAY CAUSE A SHORT CIRCUIT, ELECTRIC SHOCK OR FIRE IF THE DAMAGED CABLE IS CONTINUED TO BE USED.



CAUTION (INDICATES THAT INCORRECT OPERATION PRESENTS POSSIBILITY OF INJURY TO THE USER OR DAMAGE TO THE UNIT.)

- DO NOT USE THE THE POWER PACK IN EXCESSIVELY HUMID PLACE. THE CONDENSATION OF VAPOR ON OR INSIDE OF THE UNIT CAUSES A MALFUNCTION, A SHORT CIRCUIT, FIRE AND A ELECTRIC SHOCK.
- DO NOT USE THE POWER PACK WHERE CORROSIVE GASES AND CHEMICALS POSSIBLY EXIST.
- THE AMBIENT TEMPERATURE SHOULD BE IN THE RANGE OF 0° ~ 40° C.
- KEEP THE UNIT AWAY FROM CHILDREN.
- AVOID ANY HEAVY SHOCK TO THE POWER PACK. DO NOT DROP IT!
- KEEP ANY LIQUIDS (OIL, WATER, ETC.) OFF THE UNIT. IF ANY LIQUID HAPPENS TO GET INTO THE UNIT, STOP THE OPERATION AND CONTACT YOUR NEAREST DEALER FOR REPAIR.
- DO NOT PUT ANY HEAVY GOODS ON THE CABLE.
- AVOID EXPOSURE TO DIRECT RAY OF THE SUN, HOT BLAST, OR HEATER AIR.
- NEVER UNPLUG THE CURLED CORD WHEN UNDER OPERATING OR HIGH VOLTAGE WILL GENERATE AND DAMAGE THE UNIT.
- WHEN UNPLUGGING, ALWAYS HOLD THE PLUG (NOT THE CABLE) AND PULL.
- ALWAYS UNPLUG THE A.C CABLE WHEN REPLACING THE FUSE, CLEANING UP THE UNIT, OR DOING ANY OTHER MAINTENANCE FOR THE UNIT.
- DO NOT USE BENZINE, ALCOHL, PAINT THINNER OR OTHER VOLATILE SOLVENT TO CLEAN THE UNIT.
- ALWAYS UNPLUG THE A.C. CABLE WHEN LEAVING YOUR WORKSHOP.

※ THE WORD "REMOTE SWITCH" IN THE TEXT STANDS FOR THE REMOTE SWITCH ON THE HANDPIECE. (PLEASE REFER TO THE MANUAL OF THE HANDPIECE.)

1. ACCESSORIES





- 1). AC CABLE..... (CA10 FOR P201; CA11 FOR P211; CA12 FOR P221) X 1PC.
- 2). RUBBER CRADLE..... (RM11) X 1PC.
- 3). FUSE..... (1A125VM FOR P101 AND P111; 0.5A250VMT FOR P121) X 2PCS.

2. FEATURES

- DESIGNED TO BE COMPACT AND LIGHT WEIGHT. ALSO COMPATIBLE WITH OUR 7 SERIES HANDPIECES.
- COMPATIBLE WITH THE REMOTE SWITCH ON THE HANDPIECE TO BE ABLE TO SWITCH ON AND OFF WITHOUT REACHING OUT TO THE POWER PACK; USEFUL ESPECIALLY WHEN EMPLOYING THE EXTENSION CORD FOR THE HANDPIECE.
- WHENEVER THE HANDPIECE IS STARTED AND STOPPED, THE SHORT BEEP WILL SOUND TO LET YOU KNOW THE SWITCHING IS OPERATED.
- ON/OFF SWITCH CAN BE CONTROLLED WITH YOUR LIGHT FINGER TOUCH.
- EMPLOYING THE CARRYING HANDLE FOR YOUR CONVENIENCE TO CARRY.

3. NAMES OF PARTS AND FUNCTIONS

- ① MAIN SWITCH
ON AND OFF THE POWER SUPPLY (| : ON ○ : OFF)
- ② POWER SUPPLY LAMP
GREEN LIGHT WILL BE ON WHEN THE MAIN SWITCH IS ON, INDICATING THE INPUT POWER SUPPLY.
- ③ POWER CONTROL KNOB
TO CONTROL THE OUTPUT POWER.
- ④ ON/OFF SWITCH
TO CONTROL "ON/OFF" ON THE FRONT PANEL OF THE POWER PACK. ONE PUSH TO BE "ON" AND ANOTHER PUSH TO BE "OFF".
- ⑤ OUTPUT LAMP
GREEN LIGHT INDICATES OUTPUT POWER SUPPLY TO THE HANDPIECE IS ON.
- ⑥ ULTRASONIC SOCKET
A SOCKET FOR CONNECTING THE POLYTOR HANDPIECE.
- ⑦ OVER LOAD ALARM LAMP
RED LIGHT WILL BE ON AND THE OUTPUT CURRENT WILL BE SHUT DOWN WHEN THE SAFETY SYSTEM ACTUATES.
THE SAFETY SYSTEM WILL ACTUATE IF THE OUTPUT CURRENT RISES TO 0.32A.
- ⑧ AC SOCKET
USE THE RIGHT CABLE FOR THE RIGHT POWER PACK.
- ⑨ FUSE HOLDER
WHEN REPLACING THE FUSE, USE A SCREWDRIVER TO UNSCREW THE HOLDER.
- ⑩ FOOT SWITCH SOCKET
ONCE THE FOOT SWITCH IS CONNECTED TO THE POWER PACK, THE ON/OFF SWITCH ON THE FRONT PANEL WILL NO LONGER OPERATABLE.
- ⑪ BUZZER TRIMMING
TO ADJUST THE VOLUME OF THE BEEP SOUND.
- ⑫ CARRYING HANDLE



3. OPERATIONS

○ WITHOUT USING THE FOOT SWITCH

- ① PLUG IN THE A.C. CABLE
- ② CONNECT THE HANDPIECE TO THE ULTRASONIC SOCKET.
- ③ TURN THE POWER CONTROL KNOB ALL THE WAY TO THE LEFT (COUNTER-CLOCKWISE) THIS IS THE MINIMUM POWER.
- ④ TURN THE MAIN SWITCH ON. (POWER LAMP WILL BE GREEN)
- ⑤ TO RUN THE HANDPIECE, PUSH THE REMOTE SWITCH OF THE HANDPIECE OR ON/OFF SWITCH ON THE FRONT PANEL.
- ⑥ TURN THE POWER CONTROL KNOB TO ADJUST THE OUTPUT POWER TO THE APPROPRIATE POSITION FOR YOUR WORK.
- ⑦ TO STOP THE HANDPIECE, PUSH THE REMOTE SWITCH OR ON/OFF SWITCH OF THE POWER PACK AGAIN.

*WHEN THE SAFETY SYSTEM ACTUATES (THE MOTOR STOPS AND THE OVER LOAD LAMP TURNS RED), PUSH THE REMOTE SWITCH OR ON/OFF SWITCH AGAIN TO RESET.

○ USING THE FOOT SWITCH

- ① CONNECT THE FOOT SWITCH TO THE FOOT SWITCH SOCKET ON THE BACK OF THE POWER PACK.
 - ② PLUG IN THE A.C. CABLE.
 - ③ CONNECT THE HANDPIECE TO THE ULTRASONIC SOCKET.
 - ④ TURN THE POWER CONTROL KNOB ALL THE WAY TO THE LEFT (COUNTER-CLOCKWISE) THIS IS THE MINIMUM POWER.
 - ⑤ TURN THE MAIN SWITCH ON. (POWER LAMP WILL BE GREEN)
 - ⑥ HOLD THE HANDPIECE SECURELY AND DEPRESS THE PEDAL OF THE FOOT SWITCH TO RUN THE HANDPIECE.
 - ⑦ TURN THE POWER CONTROL KNOB TO ADJUST THE OUTPUT POWER TO THE APPROPRIATE POSITION FOR YOUR WORK.
FOR VC301 (VARIABLE SPEED CONTROL TYPE), DEPRESS THE PEDAL ALL THE WAY AND WITH KEEPING THE POSITION, ADJUST THE POWER WITH POWER CONTROL KNOB TO THE APPROPRIATE POWER FOR YOUR WORK. AFTER THEN, CONTROL THE POWER BY THE PEDAL.
 - ⑧ TO STOP THE HANDPIECE, RELEASE THE PRESSURE TO THE PEDAL. FOR FS211 WITH "A-MODE", DEPRESS THE PEDAL AGAIN TO STOP THE HANDPIECE.
- *WHEN THE SAFETY SYSTEM ACTUATES (THE MOTOR STOPS AND THE OVER LOAD LAMP TURNS RED), ONCE, TURN IT OFF AS ⑧, THEN DEPRESS THE PEDAL AGAIN TO START THE MOTOR.

4. OPTION ACCESSORIES

◀ FOOT SWITCH ▶

- FS201 ON-OFF TYPE FOOT SWITCH
REMAINS ON AS LONG AS PRESSED.
TO TURN OFF, RELEASE THE PRESSURE.
- FS211 TWO INTERCHANGEABLE OPERATION MODES
A-MODE..... REMAINS ON ONCE PRESSED AND PRESS AGAIN TO TURN OFF
B-MODE..... SAME FUNCTION AS FS201
- VC301 VARIABLE SPEED CONTROL TYPE
THE MOTOR SPEED DEPENDS ON HOW FAR THE PEDAL IS DEPRESSED.

◀ EXTENSION CORD ▶

- CB311..... TO CONNECT THE POWER PACK TO THE CURLED CORD OF THE HANDPIECE.
(3m LONG) ONLY ONE EXTENSION CORD CAN BE CONNECTED. IF CONNECTING TWO OR MORE EXTENSION CORD, THE REMOTE SWITCH MAY NOT BE FUNCTIONED WELL.